

Doctor Sight Mounting Adapter Installation Instructions: Standard Trijicon ACOG

Parts Included:

- Winged Doctor mounting adaptor
- Lower strap piece
- Two (2) 6-32 x 1/2" socket head cap screws
- Two (2) 6-32 x 3/8" button socket cap screws
- 5/64" hex key

**CAUTION: REMOVE MAGAZINE AND VISUALLY CHECK CHAMBER
TO MAKE SURE THAT FIREARM IS UNLOADED.**

This mount is designed for use on Trijicon ACOG series optical gun sights as a piggyback mount for the Doctor sight as a secondary CQB (Close Quarters Battle) sight system. Be aware that, because of the length of the Doctor sight, this mount will not fit NSN series ACOGs such as the TA01NSN version (with the factory-installed peep sight).

To install this mount, Pre-assemble the upper mount section and lower strap piece with the flange facing to the rear. Press the assembly on over the rear ocular section of the ACOG with the flange wrapping around the back of the ACOG. Center and level the winged mount piece atop the ACOG's eyepiece, and then tighten the lower strap piece using the 6-32 hex socket cap screws until the unit is secure on the scope.

THANKS FOR YOUR BUSINESS!