

***JPoint Mounting Adapter Installation Instructions:
Smith & Wesson M41 (5.5" bull barrel)***

Parts Included:

- JPoint mounting adaptor
- Two (2) 6-32 x 3/8" button socket cap screws
- One (1) 8-32 x 1/4" stainless set screw

***CAUTION: REMOVE MAGAZINE AND VISUALLY CHECK CHAMBER
TO MAKE SURE THAT FIREARM IS UNLOADED.***

Remove the slide assembly from the frame and lock it in a padded vice. Remove the rear sight from the dovetail. If the sight has been secured with Loctite, it may be necessary to apply some heat to the sight base before attempting to remove the sight. A sight press is ideal for removing tightly-fitted sights, though a piece of brass or aluminum rod stock can be used to apply force to the bottom of the dovetail section of the sight base without damaging it.

Once the old sight is removed, press in the JP adapter, center it up and Loctite the set screws in place. Install the JPoint on top using the 6-32 button head screws provided.

THANKS FOR YOUR BUSINESS!