

***JPoint Mounting Adapter Installation Instructions:
Bomar sight cuts***

Parts Included:

- JPoint mounting adaptor
- One (1) 6-48 x 3/8" oval socket screw

***CAUTION: REMOVE MAGAZINE AND VISUALLY CHECK CHAMBER
TO MAKE SURE THAT FIREARM IS UNLOADED.***

This JPA-BM adapter will fit in any melted-in Bomar BMCS sight cut.

Remove the slide assembly from the pistol frame and lock it in a padded vise. Remove the rear sight from the dovetail. If the sight has been secured with Loctite, it may be necessary to apply heat to the sight base before attempting to remove the sight. A sight press is ideal for removing tightly-fitted sights, though a piece of brass or aluminum rod stock can be used to apply force to the bottom of the dovetail section of the sight base without damaging it.

Once the old sight is removed, press in the JP adapter and center it. Secure the mount with the 6-48 oval head socket screw using a small amount of loctite thread locker on the threads. Install the JPoint on top using the 6-32 button head screws provided.

THANKS FOR YOUR BUSINESS!