

***JPoint Mounting Adapter Installation Instructions:
EAA Witness Supersight***

Parts Included:

- JPoint mounting adaptor
- Two (2) 6-32 x 3/8" button socket cap screws
- One (1) 8-32 x 1/4" stainless set screw

Installation Instructions

CAUTION: REMOVE MAGAZINE AND VISUALLY CHECK CHAMBER TO MAKE SURE THAT FIREARM IS UNLOADED.

Remove the slide assembly from the frame and lock in a padded vice. Remove the rear sight from the dovetail. If the sight has been secured with Loctite, it may be necessary to apply some heat to the sight base before attempting to remove it. A sight press is best for removing tightly fitted sights, however, a piece of brass or aluminum rod stock can be used to apply force at the bottom of the dovetail section of the sight base without damaging the sight. With the sight removed, press in the JP adapter, center it up and tightly secure the set screws in place. Install the JPoint on top using the 6-32 button head screws provided.

THANKS FOR YOUR BUSINESS!