

JPoint Mounting Adapter Installation Instructions: JPoint adapter with integral guard for MIL-STD-1913 (Picatinny) rail interface

Parts Included:

- JPoint mounting adapter
- Two (2) 6-32 x 3/8" button socket cap screws
- Two (2) 10-32 x 1¼ flat head cap screws
- Mounting clamp plate
- T20 Torx key
- One (1) JPA-SHIM (see additional instruction sheet)

CAUTION: REMOVE MAGAZINE AND VISUALLY CHECK CHAMBER TO ENSURE THAT FIREARM IS UNLOADED.

The JPA-CPG mounting adapter is made to fit any MIL-STD-1913 Picatinny rail and includes guard wings as an integral feature to protect the sight from damage. The mount's height allows for co-witnessing of iron sights with A2 sight systems on A2- or M4-type weapons.

Use the supplied 6-32 screws to attach the JPoint to the mount and the included Torx key to tighten the clamp screws of the mount to affix it to the rail interface. For elevation, a JPA-SHIM has been included. Refer to that part's instruction sheet for use.

THANKS FOR YOUR BUSINESS!