## JPoint Mounting Adapter Installation Instructions: 1-inch and 30mm scope-top secondary sight system

## Parts Included:

- · Upper JPoint mounting adaptor piece
- · Lower strap piece
- Two (2) 6-32 x 3/8" button socket cap screws
- Four (4) 6-32 x 1/2" Torx socket head cap screws
- Two (2) adapter piece halves
- T15 Torx wrench

## CAUTION: REMOVE MAGAZINE AND VISUALLY CHECK CHAMBER TO MAKE SURE THAT FIREARM IS UNLOADED.

The two-piece clamp style JPoint mounting adapter can be easily installed and removed from your scope tube, whether 1-inch or 30mm. For a 1-inch diameter scope, position one half of the included adapter pieces onto each piece of the JPoint mount before inserting the scope such that the adapters form a ring that decreases the mount's effective diameter to accommodate a 1-inch scope tube.

While this particular mount is relieved on one end to clear a scope ring if it overhangs, you can mount the adapter anywhere you see fit since eye relief on the JPoint is not a concern. It can be located forward of the turret or mounted to the side at a 90° angle if you so desire, though be aware that side mounting would reverse the elevation/windage adjustments of the JPoint sight. Also, the mount has four screw holes allowing the mount to be reversed for added versatility.

To accompany this mount, you might need the JPA-SHIM8 shim pack if extra elevation is needed to clear a high turret. However, it is not necessary to elevate the sight completely above the turret since a sight picture through the JPoint can still be achieved if the lens is partially occluded. For military, law enforcement or any application that requires extra protection for the sight, we also make a protective guard wing assembly (JPA-GUARD, shown at right) that fits between any JPoint mount and the sight.



JPoint shown mounted forward of turret with wing guard installed.

Visit us at www.jprifles.com

Rev. 05.11

P.O. Box 378, Hugo, MN 55038 · Voice: 651-426-9196 · Fax: 651-426-2472