



JP Quick Detach Adjustable Height Front Sight

JPFS-A (Sight base only) **OR**

JPFS-ALS (base and Lyman globe with Shaver inserts)

CAUTION: REMOVE MAGAZINE AND VISUALLY CHECK CHAMBER TO VERIFY THAT WEAPON IS CLEAR.

The JP detachable sight is designed to interface with any Picatinny rail type gas blocks or sight blocks. It will accept any standardized target globes, and is compatible with standard A-2 handle mounted rear sights or most any detachable rear sight systems for flat top upper receivers. If maximum possible sight radius is preferred, order the JP optional front sight base which will allow mounting of the front sight at the muzzle of your rifle. The front sight mounting block is available in .730, .875 or .925 bore versions for the most popular barrel configurations. A set of 10 various extra fine posts, apertures, cross hairs etc. made by Lee Shaver to fit this sight is available for \$19.95. Another great accessory compatible with our gas block is our anti-cant detachable level to prevent cant or insure consistent cant.

Make sure that your gas block or front sight mounting block is level with the receiver as it does not take much front sight cant to exceed the rear sight adjustment range. We recommend using Loc-Tite #609 as a sealant on the gas block or front sight block in addition to detenting the set screws in the barrel to insure that the mounting block will not shift when the front sight receives a blow.

This sight is completely height adjustable by using the side lock screw on the clamping interface of the base to allow the globe slider piece to slide up and down through its range of adjustment. In addition, a 6x32 set screw, accessed on the bottom of the front sight base can be adjusted to touch the slider and is sealed in place with a thread locker to provide a permanent lower setting and prevent a blow from moving the slider. This screw can also be used to achieve a fine adjustment in height.

As a point of reference, if using an A-2 type rear sight system with this front sight, it should be adjusted so it's height allows for a zero elevation setting on the rear sight at your preferred primary zero. This would normally be 200 to 300 yards depending on your application. Use a dial caliper to raise the slide .150 from the base as a starting point. If using a more sophisticated receiver sight like the RPA Tracker, you may choose a lower front sight position to get a tighter cheek weld on the stock, and adjust the rear accordingly. Once the sight is set and locked, it can be removed and replaced without losing zero.

THANKS FOR YOUR BUSINESS!!

Visit us at www.jp Rifles.com

P.O. Box 378, HUGO, MN 55038 • VOICE: 651-426-9196 • FAX: 651-426-2472